

# PrintaFix Basic


The best solution for 3D Printing



APRINTA PRO

## Manual

PrintaFix Basic is easy to apply and to remove with just 3 easy steps your 3D Printer is ready for your imaginations and designs.



1 - Shake the bottle well for 5 seconds and take the printbed out of the 3D Printer. Remove any left residue from previous prints. Every component should be at room temperature.

2 - From a distance of 10cm or 4" apply PrintaFix Basic in overlapping circles on the printbed. Avoid uncovered areas that could affect the adhesion. Let it dry for 30sec.


3 - Place the printbed back into the 3D printer and level the printbed as usual. Start the printing process with our recommended settings to achieve the best results.

## Recommended settings


PrintaFix Basic works with the most common filaments, 3D printers and printbeds. For optimal adhesion we have made hundreds of testprints to develop the best settings for a perfect result.

**ABS** 3mm brim for best adhesion

printing temperature in °C



printbed temperature in °C



**PLA**

printing temperature in °C

